

EXAMPLE WIRING FOR LEFT OR RIGHT SIDE  
GATE CONTROL

NOTE 1

CONNECT TWISTED PAIR SHIELD TO NEGATIVE  
TERMINAL.

NOTE 2

ALL SOLENOIDS MUST HAVE DIODE FITTED  
ACROSS SUPPLY TERMINALS ON SOLENOID.

